KENW00D

KAC-X40

FOUR CHANNEL POWER AMPLIFIER ▶ page 2-7

INSTRUCTION MANUAL

四聲道功率放大器 ▶ 8-13頁

使用說明書

四声道功率放大器 ▶ 14-19页

使用说明书

Kenwood Corporation

Safety precautions

▲WARNING

To prevent injury or fire, take the following precautions:

- Mounting and wiring this product requires skills and experience. For safety's sake, leave the mounting and wiring work to professionals.
- When extending the ignition, battery, or ground wires, make sure to use automotive-grade wires or other wires with a 8 mm² (AWG 8) or more to prevent wire deterioration and damage to the wire coating.
- To prevent a short circuit, never put or leave any metallic objects (such as coins or metal tools) inside the unit.
- If the unit starts to emit smoke or strange smells, turn off the power immediately and consult your Kenwood dealer.
- Do not touch the unit during use because the surface of the unit becomes hot and may cause burns if touched.

ACAUTION

To prevent damage to the machine, take the following precautions:

- Be sure the unit is connected to a 12V DC power supply with a negative ground connection.
- Do not open the top or bottom covers of the unit.
- Do not install the unit in a spot exposed to direct sunlight or excessive heat or humidity. Also avoid places with too much dust or the possibility of water splashing.
- When replacing a fuse, only use a new one with the prescribed rating. Using a fuse with the wrong rating may cause your unit to malfunction.
- To prevent a short circuit when replacing a fuse, first disconnect the wiring harness.

NOTE

- If you experience problems during installation, consult your Kenwood dealer.
- If the unit does not seem to be working right, consult your Kenwood dealer.

Cleaning the unit

If the front panel gets dirty, turn off the power and wipe the panel with a dry silicon cloth or soft cloth.

▲CAUTION

Do not wipe the panel with a hard cloth or a cloth dampened by volatile solvents such as paint thinner and alcohol. They can scratch the surface of the panel and/or cause the indicator letters to peel off.

To prevent battery rise

When the unit is used in the ACC ON position without turning the engine ON, it depletes the battery. Use it after starting the engine.

Protection function

The protection function is activated in the following situations:

This unit is equipped with a protection function for protecting this unit and your speakers from various accidents or problems that can occur.

When the protection function is triggered, the Power indicator goes OFF and the amplifier stops operating.

- · When a speaker wire may be short-circuited.
- · When a speaker output contacts ground.
- $\boldsymbol{\cdot}$ When the unit malfunctions and a DC signal is sent to the speaker output.
- When the internal temperature is high and unit won't operate.
- When a ground wire of the center unit (cassette receiver, CD receiver, etc.)
 or this unit is not connected to a metal part serving as an electrical ground
 passing electricity to the battery's negative


 terminal.


Wiring


- Take the battery wire for this unit directly from the battery. If it's connected to the vehicle's wiring harness, it can cause blown fuses etc.
- If a buzzing noise is heard from the speakers when the engine is running, connect a line noise filter (optional) to each of the battery wire.
- Do not allow the wire to directly contact the edge of the iron plate by using Grommets.
- Connect the ground wire to a metal part of the car chassis that acts as an electrical ground passing electricity to the battery's negative ⊝ terminal. Do not turn the power on if the ground wire is not connected.
- Be sure to install a protective fuse in the power cord near the battery. The
 protective fuse should be the same capacity as the unit's fuse capacity or
 somewhat larger.
- For the power cord and ground, use a vehicle type (fireproof) power wring cord with a current capacity greater than the unit's fuse capacity. (Use a power wiring cord with a diameter of 8 mm² (AWG 8) or greater.)
- When more than one power amplifier are going to be used, use a power supply wiring wire and protective fuse of greater current-handling capacity than the total maximum current drawn by each amplifier.

Speaker Selection

- The rated input power of the speakers that are going to be connected should be greater than the maximum output power (in Watts) of the amplifier. Use of speakers having input power ratings that are less than the output power of the amplifier will cause smoke to be emitted as well as damage.
- Use speakers that have an impedance of 2Ω or greater. When more than one set of speakers are going to be used, calculate the combined impedance of the speakers and then connect suitable speakers to the amplifier.







Accessories

Part name	External View	Number of Items
Self-tapping screws (\emptyset 5 × 18 mm)		4
Terminal cover (Power terminal)		1
Hexagon Wrench		1

Installation procedure

Since there are large variety of settings and connections possible according to applications, read the instruction manual well to select the proper setting and connection.

- 1. Remove the ignition key and disconnect the negative \bigcirc terminal of the battery to prevent short circuits.
- 2.Set the unit according to the intended usage.
- 3. Connect the input and output wires of the units.
- 4. Connect the speaker wires
- 5.Connect the power wire, power control wire and grounding wire following this order.
- 6.Install the installation fittings in the unit.
- 7. Attach the unit.
- 8.Connect the negative

 terminal of the battery.

▲CAUTION


- Do not install in the below locations;
 (Unstable location, In a location that interferes with driving, In a location
- that gets wet, In a dusty location, In a place that gets hot, In a place that gets direct sunlight, In a location that gets hit by hot air)

 Do not install the unit under the carriet. Otherwise heat build-up occurs
- Do not install the unit under the carpet. Otherwise heat build-up occurs and the unit may be damaged.
- Install this unit in a location which allows heat to easily dissipate.
 Once installed, do not place any object on top of the unit.
- The surface temperature of the amplifier will become hot during use. Install
 the amplifier in a place where people, resins, and other substances that are
 sensitive to heat will not come into contact with it.
- This unit has cooling fan to decrease the internal temperature. Do not
 mount the unit in a place where the cooling fan and ducts of the unit are
 blocked. Blocking these openings will inhibit the cooling of the internal
 temperature and result in malfunction.
- When making a hole under a seat, inside the trunk, or somewhere else in the vehicle, check that there is nothing hazardous on the opposite side such as a gasoline tank, brake pipe, or wiring harness, and be careful not to cause scratches or other damage.
- Do not install near the dashboard, rear tray, or air bag safety parts.
- The installation to the vehicle should securely fasten the unit to a place in which it will not obstruct driving. If the unit comes off due to a shock and hits a person or safety part, it may cause injury or an accident.
- After installing the unit, check to make sure that electrical equipment such as the brake lamps, turn signal lamps and windshield wipers operate normally.

▲WARNING

To prevent fire caused by a short in the wiring, connect a fusible link or breaker nearby the battery's positive terminal.






▲CAUTION


- If sound is not output normally, immediately turn power off and check connections.
- Be sure to turn the power off before changing the setting of any switch.
- If the fuse blows, check wires for shorts, then replace the fuse with one of the same rating.
- Check that no unconnected wires or connectors are touching the car body. Do not remove caps from unconnected wires or connectors to prevent short circuits.
- Connect the speaker wires to appropriate speaker connectors separately. Sharing the negative wire of the speaker or grounding speaker wires to the metal body of the car can cause this unit to fail.
- After installation, check that the brake lamps, winkers, and wipers work properly.


* Commercially available parts




System examples


■ 4-channel system







■ High-power 2-channel system







■ 2-channel + Subwoofer system (1)






■ 2-channel + Subwoofer system (2)





NOTE

The control panel locates under the front side cover. Remove the cover to access to its controls for adjustment. (See page 3)



This is a 4 channel amplifier including 2 stereo amplifiers in a body. One amplifier is referred to as amplifier A and the other is amplifier B. This unit is compatible with a large variety of systems by combining the switches and functions described in the following.

- 1 Fuse (25 A x 2)
- (2) Battery terminal
- (3) Ground terminal
- (4) Power control terminal

Controls the unit ON/OFF.

NOTE

Controls the unit power. Be sure to connect it with all the systems.

(5) Speaker output terminals (A.ch/B.ch)

• Stereo Connections:

When you wish to use the unit as a stereo amplifier, stereo connections are used. The speakers to be connected should have an impedance of 2Ω or greater. When multiple speakers are to be connected, ensure that the combined impedance is $2\Omega\,\text{or}$ greater for each

Bridged Connections:

When you wish to use the unit as a high-output monaural amplifier, bridged connections are used. (Make connections to the LEFT channel ♠ and the RIGHT channel ♠ SPEAKER OUTPUT terminals.)

The speakers to be connected should have an impedance of 4Ω or greater. When multiple speakers are to be connected, ensure that the combined impedance is 4Ω or greater.

▲CAUTION

The rated input of the speakers should be no less than the maximum output of the amplifier. Otherwise malfunction may result.

(6) LINE IN terminal (A.ch/B.ch)

7 LINE OUT terminal

These jacks output respectively the signals input to amplifiers A and B.

They always output the stereo signals regardless of the position of the "OPERATION" switch.

(8) Power indicator

When the power is turned on, the Power indicator

If the Power indicator does not light when the power is turned on, the protection function may be activated. Check whether there is any indication of trouble. (See page 2)

9 FILTER switch (A.ch)

This switch allows to apply high-pass filtering to the speaker outputs

• HPF (High-Pass Filter) position:

The filter outputs the band of higher frequencies than the frequency set with the "HPF FREQUENCY" control.

OFF position:

The entire bandwidth is output without filtering.

10 OPERATION switch (A.ch/B.ch)

The amplification methods of the signals input to amplifiers A and B can be selected independently according to the setting of this switch.

• STEREO position:

The amplifier can be used as a stereo amplifier.

MONO (Lch) position:

Amplifies the signal input from the left side only. Set to this position and make bridged connections to use as a high-power monaural amplifier. (The input right signal is not output.)

11) INPUT SELECTOR switch

This switch selects the input method of the signals to be amplified by amplifiers A and B.

• A B position:

Amplifies both of the signals input to amplifiers A and B.

A position:

Amplifies only signal input amplifier A with both amplifiers A and B.

12 FILTER switch (B.ch)

This switch allows to apply high-pass or low-pass filtering to the speaker outputs

• HPF (High-Pass Filter) position:

The filter outputs the band of higher frequencies than the frequency set with the "HPF FREQUENCY" control.

• OFF position:

The entire bandwidth is output without filtering.

• LPF (Low-Pass Filter) position:

The filter outputs the band of lower frequencies than the frequency set with the "LPF FREQUENCY" control.

The speaker output is automatically switched to monaural (L+R).

(3) HPF FREQUENCY control (A.ch/B.ch)

Sets the cutoff frequency when the "FILTER" switch is set to "HPF".

(4) BASS BOOST FREQUENCY control (B.ch)

Sets the center frequency around which the low frequency range should be boosted.

(15) BASS BOOST LEVEL control (B.ch)

Sets the level by which the low frequency range should be boosted.

16 LPF FREQUENCY control (B.ch)

Sets the cutoff frequency when the "FILTER" switch is set to "LPF".

(1) INPUT SENSITIVITY control (A.ch/B.ch)

Set this control according to the pre-output level of the center unit connected with this unit. The sensitivities of amplifiers A and B can be adjusted independently regardless of the position of the input selector switch.

NOTE

For the pre-output level, refer to the <Specifications> in the instruction manual of the

Troubleshooting Guide

What might appear to be a malfunction in your unit may just be the result of slight misoperation or miswiring. Before calling service, first check the following table for possible problems.

PROBLEM	POSSIBLE CAUSE	SOLUTION
No sound. (Blown fuse.)	 Input (or output) cables are disconnected. Protection circuit may be activated. Volume is too high. The speaker cord is shorted. 	 Connect the input (or output) cables. Check connections by referring to <protection function="">.</protection> Replace the fuse and use lower volume. After check the speaker cord and fixing the cause of the short, replace the fuse.
The output level is too small (or too large).	The input sensitivity adjusting control is not set to the correct position.	Adjust the control correctly referring to <controls>.</controls>
The sound quality is bad. (The sound is distorted.)	 The speakers wire are connected with wrong ⊕ /⊝polarity. A speaker wire is pinched by a screw in the car body. 	 Connect them properly checking the ⊕ / ⊝ of the terminals and wires well. Connect the speaker wire again so that it is not pinched by anything.
	The switches may be set improperly.	 Set switches properly by referring to <controls>.</controls>

Specifications

Specifications subject to change without notice.

Audio Section	
Max Power Output	W 008
Rated Power Output (+B = 12.0 V)	
Nation Fower Output (+D = 12.0 V)	45 \\\ > 4
Normal (4 Ω) (20 HZ $-$ 20 KHZ, 0.05 % 1HD)	45 W X 4
(2 Ω) (1 kHz, 0.5 % 1HD)	65 W × 4
Normal (4 Ω) (20 Hz $-$ 20 kHz, 0.05 % THD)	120 W × 2
Rated Power Output (+B = 14.4 V)	
Normal (4 Ω) (20 Hz – 20 kHz, 0.05 % THD)	70 W × 4
Normal (4 Ω) (20 Hz $-$ 20 kHz, 0.05 % THD)	100 W × 4
Bridged (4 Ω) (1 kHz, 0.5 % THD)	200 W × 2
3 1	
Frequency Response (+0, -3 dB)	5 Hz = 70 kHz
Sensitivity (rated output) (MAX)	021/
Frequency Response (+0, –3 dB) Sensitivity (rated output) (MAX.)	5.0 V
Input Impedance	10 kO
Input Impedance	10 KL2
Signal to Noise Ratio.	IU5 QB
Low Pass Filter Frequency (-24 dB/oct.) (B channel)	40 – 200 Hz (variable)
FIGUREASS FILLER FREQUENCY (-1.2 GB/OCL)	4U = 7UU E7 (Variable)
Bass Boost Circuit (B channel)	0 – +18 dB (variable)
Bass Boost Frequency (B channel)	40 – 100 Hz (variable)
General	
Operating Voltage	14 4 V (11 – 16 V allowable)
Current Consumption	
Installation Circ (M × H × D)	200 v 65 v 206 mm
Installation Size (W × H × D)	
weight	4.6 Kg

安全注意事項

▲警告

為了防止受傷和火災,請遵守下列注意事項。

- · 安裝本產品和連接導線需要一定的技能和經驗。 為了保證安全,應請 專業人員完成安裝和連接導線作業。
- · 當延長點蓄電池導線和接地導線時,請使用車輛用導線或8mm² (AWG 8) 以上的導線,以防止導線劣化和被覆面的損傷。
- · 為了防止短路等事故,請勿將金屬物品(硬幣,工具等)掉落在裝置中。
- · 萬一裝置冒煙或有異味時,請立即關閉電源,並與建伍經銷商洽談。
- · 在使用中請盡量不要接觸機器表面。因為機器在使用中表面發熱會燙傷 人體。

▲注意

為了防止裝置發生故障,請遵守下列注意事項,正確操作和使 用。

- · 請以負接地線的12V直流電源向本裝置供電。
- · 請勿打開頂部和底部的蓋子。
- · 請勿將本裝置安裝在曝露於直射陽光,高溫或高濕, 水可能飛濺的或 有灰塵的地方。
- · 更換保險絲時,請更換規定容量相同的保險絲, 如使用不同容量的保險絲,可能會造成裝置的故障。
- · 更換保險絲時,為了防止短路事故,請先拔下來電源線束再進行更換。

註

- · 安裝有困難時,請與建伍經銷商洽談。
- · 如果仍不能恢復正常時,請與建伍經銷商洽談。

裝置的保養

如果外表髒污時,請關閉電源,使用干燥的硅布或柔軟的布匹擦拭。

▲注意

請勿使用硬布或塗料稀釋劑,酒精等揮發性溶劑,以免損外壞表面或將 所附指示字符擦掉。

防止蓄電池全部放電

當本機在ACC ON位置使用而不開動發動機時,將消耗蓄電池的電量。 請在開動了發動機之後使用。

保護功能

在以下場合中保護功能被激活

本機裝有保護功能,可以保護本機以及揚聲器不會受到可能發生的各種意外事故的損害。

當保護功能被觸發時,電源指示燈將熄滅,放大器也停止工作。


- 當揚聲器纜線短路時。
- · 當揚聲器的輸出接地時。
- · 當本機出現誤動作,有 DC(直流) 信號傳送到揚聲器輸出端時。
- 內部高溫不能動作時。
- · 當中心裝置(卡式接收機、CD 接收機等)或本機的地線沒有連接到作 為電氣地線的金屬部件而向電池負極 ⊝ 端子輸送電流時。


接続


- · 請將本機的蓄電池連接線直接與蓄電池連接。 如果與汽車的配線束連接,將產生燒毀保險絲等故障。
- · 如果發動機運轉時從揚聲器中發出噪音,可以在電池的每根連線上加一個線路噪音過濾器(選購件)。
- · 使用絕緣圈,以防纜線直接接觸貼片的邊緣。
- 將接地線連接到車架的金屬部位,車架起到車輛電氣接地的作用,將電流傳遞到電池的負極 ○。如果接地線沒有連接就不要打開電源開關。
- · 應務必在蓄電池附近的電源連接線上設置保險絲。 保險絲的規格應該 與本機的保險絲容量相同或者略大。
- · 對於電源連接線和接地線,請使用電流容量大於本機保險絲容量的汽車用(防火)電源連接線。 (請使用截面積為8mm²(AWG10)或者以上的電源連接線。)
- ·當使用多個功率放大器時,電源導線的電流容量及保險絲的容量要大於各個放大器的使用電流之和的最大值。

揚聲器選擇

- 準備連接的揚聲器的額定功率要大於放大器的最大輸出功率。如果揚聲器的額定功率小於放大器的最大輸出功率則會導致揚聲器冒煙以至損壞。
- · 使用的揚聲器的阻抗必須大於或等於 2 歐姆。 當使用一組揚聲器時, 必須在計算揚聲器的總阻抗之后,再連接合适的揚聲器。







附件

零件名稱	外觀	項目數量
自攻絲螺絲 (φ5 × 18 mm)		4
端子套(電源端子)		1
六角扳手		1

根據使用場合的不同,可能有多種不同的連接及設定方式請務必仔細閱讀 使用說明書,選擇適當的連接和設定。

- 1. 拔取點火鑰匙,拆掉電池負極 ⊝ 端子,以防短路。
- 2. 根據使用目的,設置本機到妥當位置。
- 3. 連接本機的輸入和輸出纜線。
- 4. 連接揚聲器纜線。
- 5. 連接電源線,電源控制纜線及地線,不可違反此順序。
- 6. 向本機安裝裝配部件。
- 7. 安裝本機
- 8. 連接電池的負極 ○。

▲注意

- 不得在下列位置安裝;
- (不穩定的位置,妨礙駕駛車輛的位置,潮溼的位置,灰塵較多的位 置,受熱的位置,陽光直射的位置,熱氣接觸的位置)不可將本裝置安裝在絨毯底下, 否則,蓄熱會導致本裝置損壞。
- · 將本裝置安裝在熱量容易發散的地點。
- 一旦安裝完畢,不可在其上放置其它物品
- ·機器使用過程中,機體會表面發熱昇溫。 所以其安裝地點應該是人 體,樹脂及其它熱敏感物質不易觸及的地方。
- 本裝置設有冷卻風扇用來降低內部溫度。 請不要安裝在遮擋冷卻風扇 和風管的位置。 堵塞通風孔的後果是內部溫度升高,引起系統故障。
- 在車座,行李箱底部或車子其它部位打洞時,應確認其背面沒有會受 到損壞的物件,諸如油箱、剎車用配管或線路管套等,千萬不可擦傷 或損壞這些物品。
- 不可安裝在駕駛室儀表板,尾部底板或保險氣囊等部件之上。
- · 將本機安裝在車內時,應確保固定牢靠,且不會對駕車造成妨礙。 如 果因為沖擊造成本機脫落且撞及人體或保險部件,就會導致傷害或事
- 在本裝置安裝之後,應該確認電氣設備,比如剎車燈、轉向信號燈以 及雨刷等操作正常。

▲警告


為了防止短路所引起的火災,在電池的正極 附近連接保險絲或斷電器。




▲注意


- · 如果聲音輸出不正常,應立即關斷電源並 檢查連接是否正確。
- · 在變更開關的設定時,必須首先切斷電源。
- · 當保險絲熔斷後,要檢查纜線是否有短 路,並更換上相同規格的保險絲。
- ·檢查是否有尚未連接的纜線或與車體相接 觸的端頭。 未連接纜線及其端部的保護帽 不可拆掉,以防短路。
- · 揚聲器的纜線要分別連接到各自的端子。 共用揚聲器的負極纜線或將揚聲器端子接 地到汽車的金屬部分,都會導致本機停止 工作。
- · 安裝之後,請檢查汽車的剎車燈、方向指示燈、雨刷等是否正常動作。

*市售品





■ 4 通道系統







■ 大功率 2 通道系統







■ 2 通道 + 副低音揚聲器系統(1)






■ 2 通道 + 副低音揚聲器系統 (2)





控制盤設在前側蓋板的下面。 需要調整時,請取下蓋板。 (參照第9頁)



本機之機體內搭載了2台立體聲4通道放大器。 其2台放大器之中一台稱為A,另一台則稱為B。如下所記,可以對應開關切換操作及各種功 能組合系統。

- ① 保險絲 (25A × 2)
- ② 電池端子
- ③ 接地端子
- ④ P.CON(電源控制)端子

控制本機的接通/關閉。

控制本機電源。 應務必與全部系統連接。

⑤ 揚聲器輸出端子(A.ch/B.ch)

立體聲連接端子:

當您希望本機作為立體聲放大器時,必須使 用立體聲連接端子。

所連接的揚聲器的阻抗必須為2歐姆或更 高。 當多個揚聲器被連接時,必須保證每通 道的綜合阻抗大於或等於 2 歐姆。

・橋路連接端子:

當您希望本機作為大功率單聲道放大器使 用時,可以進行橋路連接。 (連接LEFT聲 道 ◆、RIGHT聲道 ⊖ 及SPEAKER OUTPUT

所連接的揚聲器的阻抗必須為 4 歐姆或更 高。 當多個揚聲器被連接時,必須保證每通 道的綜合阻抗大於或等於 4 歐姆。

▲注意

揚聲器的額定輸入功率要大於放大器的最大輸 出功率。否則,將造成損壞

⑥ LINE IN 端子 (A.ch/B.ch)

⑦ LINE OUT 端子

此端子為合成輸出分別從放大器 A 和 B輸入 的信號。

它們總是輸出立體聲信號而不管 "OPERATION"(操作)開關的設定如何。

⑧ 電源指示燈

當電源打開時,電源指示燈點亮。 如果當電源被打開,但該指示燈卻不點亮時, 也有可能是因為保護功能被激活。 請檢查是 否有出現故障的跡象。(參照第8頁)

⑨ FILTER (過濾器) 開關 (A.ch)

本開關將高通濾波用於揚聲器輸出。

·HPF(高頻通過)位置:

過濾器將輸出高於 "HPF FREQUENCY" 控制設 定值的波段。

·OFF(關閉)位置:

過濾器將不進行任何過濾處理,輸出整個波

- ⑩ OPERATION (操作) 開關 (A.ch/B.ch) 根據本開關的設定,可以選擇輸入到放大器 A 和 B 中的信號的放大方法。
 - ·STEREO(立體聲)位置: 放大器可以作為立體聲放大器使用。
 - · MONO(Lch)(單聲道-左聲道)位置: 只放大從左聲道輸入的信號。 切換到此位置 可以進行橋路連接,作為大功率單聲道放大 器使用。(輸入的右聲道信號不輸出)
- ① INPUT SELECTOR (輸入選擇) 開關 本開關可以選擇被放大器 A 和 B 處理的信號 的輸入方法。
 - · A、B 位置:

放大輸入到放大器 A 和 B 的兩種信號。

· A 位置:

使用A、B放大器處理輸入到放大器 A 的信 號。

12 FILTER (過濾器) 開關 (B.ch)

本開關可以對揚聲器的輸出進行高頻通過的或 低頻通過的渦濾處理。

·HPF(高頻通過)位置:

過濾器將輸出高於 "HPF FREQUENCY"控制設 定值的波段。

·OFF(關閉)位置:

過濾器將不進行任何過濾處理,輸出整個波 段。

·LPF(低頻涌渦)位置:

過濾器將輸出低於 "LPF FREQUENCY"控制設 定值的波段。

揚聲器的輸出將自動切換單聲道(L+R)。

③ HPF FREQUENCY (頻率)控制 (A.ch/ B.ch)

當把 "FILTER" 開關切換為 "HPF" 時,可以調整 遮斷頻率。

⑭ BASS BOOST FREQUENCY (低音提昇 **頻率)控制 (B.ch)** 設定進行提昇的低頻範圍的中央頻率。

⑮ BASS BOOST LEVEL (低音提昇)控制 (B.ch)

設定進行提昇的低頻範圍電平。

- ⑯ LPF FREQUENCY (頻率)控制 (B.ch) 當把 "FILTER" 開關切換為 "LPF" 時,可以調整 遮斷頻率。
- ⑪ INPUT SENSITIVITY(輸入敏感度)控 制(A.ch/B.ch)

根據與本放大器連接的中心裝置的前置輸入水 評調節本控制鈕。

對於放大器 A 和 B 可以分別設定其敏感度而 不管輸入選擇開關的位置如何。

註

關於中心裝置的前置輸出水平,請參考其使 用說明書。

<u>故障檢修</u>

有時被認為是故障的現象,其實是因微小的操作或配線失誤而造成。 在要求維修之前,請參照下表稍事檢查為盼。

現象	原因	排除方法
沒有聲音	· 輸入(或輸出)纜線未連接。	連接輸入(或輸出)纜線。
(保險絲跳斷)	· 保護線路可能被觸發。	· 參考 <保護功能> 一節,檢查連接狀況。
	・音量過大。	· 請更換保險絲,減小音量。
	• 揚聲器電線短路。	· 確認揚聲器線,解除短路原因後,更換保險絲。
輸出水平過低(或過高)	· 輸入敏感度調節不當,沒有位于妥當位置。	· 調節該控制器。請參考 <控制>。
聲音質量很差	· 揚聲器纜線的極性①/②連接錯誤。	· 請將纜線的極性⊕/⊝連接正確。
(聲音失真)	・揚聲器纜線的一根被車體螺釘壓迫。	· 重新連接纜線,使之不再受螺釘壓迫。
	· 開關的設定可能不妥。	· 請參考 <控制>,將開關正確設置。

規格

規格可能會變更,恕不另行通知。

音頻部 最大輸出功率 額定輸出功率 (+B = 12.0 V) 普通 (4 歐姆) (20 Hz - 20 kHz, 0.05 % THD) 45 (2 歐姆) (1 kHz, 0.5 % THD) 65 橋路 (4 歐姆) (1 kHz, 0.5 % THD) 120 額定輸出功率 (+B = 14.4 V) 普通 (4 歐姆) (20 Hz - 20 kHz, 0.05 % THD) 70 (2 歐姆) (1 kHz, 0.5 % THD) 100 橋路 (4 歐姆) (1 kHz, 0.5 % THD) 200	W × 4 W × 4 W × 2 W × 4 W × 4
頻率響應(+0, - 3 dB) 5 Hz - 敏	0.2 V 5.0 V .10 kΩ .105 dB (可變)
共同 使用電壓	47 A 286 mm

▲警告

- **为了防止受伤和火灾,请遵守下列注意事项。** ・安装本产品和连接导线需要一定的技能和经验。 为了保证安全,应请 专业人员完成安装和连接导线作业。
- ・当延长蓄电池导线和接地导线时,请使用车辆用导线或8mm² (AWG8) 以上的导线,以防止导线劣化和被覆面的损伤。
- · 为了防止短路等事故,请勿将金属物品(硬币,工具等)掉落在装置
- · 万一装置冒烟或有异味时,请立即关闭电源,并与建伍经销商洽谈。
- · 在使用中请尽量不要接触装置表面。因为装置在使用中表面发热会烫伤 人体。

▲注意

为了防止装置发生故障,请遵守下列注意事项,正确操作和使 用。

- ·请以负接地线的12V直流电源向本装置供电。
- · 请勿打开顶部和底部的盖子。
- ·请勿将本装置安装在曝露于直射阳光,高温或高湿, 水可能飞溅的或 有灰尘的地方。
- · 更换保险丝时, 请更换规定容量相同的保险丝, 如使用不同容量的保 险丝,可能会造成装置的故障。
- · 更换保险丝时, 为了防止短路事故, 请先拔下来电源线束再进行更换。

注

- 安装有困难时,请与建伍经销商洽谈。
- · 如果仍不能恢复正常时, 请与建伍经销商洽谈。

装置的保养

如果外表污脏时,请关闭电源,使用干燥的硅布或柔软的布匹擦拭。

▲注意

请勿使用硬布或涂料稀释剂,酒精等挥发性溶剂, 以免损坏外表面或将 所附指示字符擦掉。

防止蓄电池全部放电

当本机在ACC ON位置使用而不开动发动机时,将消耗蓄电池的电量。 请 在开动了发动机之后使用。

保护功能

在以下场合中保护功能被激活

本机装有保护功能,可以保护本机以及扬声器不会受到可能发生的各种意 外事故的损害。

当保护功能被触发时,电源指示灯将熄灭,放大器也停止工作。


- 当扬声器缆线短路时。
- · 当扬声器的输出接地时。
- · 当本机出现误动作, 有 DC (直流) 信号传送到扬声器输出端时。
- · 内部高温不能动作时
- · 当中心装置(卡式接收机、CD 接收机等)或本机的地线没有连接到作 为电气地线的金属部件而向蓄电池负极(-)端子输送电流时。


接线


- 请将本机的蓄电池连接线直接与蓄电池连接。 如果与汽车的配线束连 接,将产生烧毁保险丝等故障。
- · 如果发动机运转时从扬声器中发出噪音,可以在蓄电池的每根连线上加 个线路噪音滤波器(选购件)。
- · 使用保护套,以防缆线直接接触铁板的边缘。
- · 将接地线连接到车架的金属部位, 车架起到车辆电气接地的作用, 将电 流传递到蓄电池的负极(-)。 如果接地线没有连接就不要打开电源开 关。
- · 应务必在蓄电池附近的电源连接线上设置保险丝。 保险丝的规格应该 与本机的保险丝容量相同或者略大。
- ·对于电源连接线和接地线,请使用电流容量大于本机保险丝容量的汽车用(防火)电源连接线。(请使用截面积为8mm² (AWG8)或者以上 用(防火)电源连接线。 的电源连接线。)
- · 当使用多个功率放大器时, 电源导线的电流容量及保险丝的容量要大于 各个放大器的使用电流之和的最大值。

扬声器选择

- ·准备连接的扬声器的额定功率要大于放大器的最大输出功率。 如果扬 声器的额定功率小于放大器的最大输出功率则会导致扬声器冒烟以至损
- ·使用的扬声器的阻抗必须大于或等于 2 欧姆。 当使用一组扬声器时, 必须在计算扬声器的总阻抗之后, 再连接合适的扬声器。







附件

零件名称	外观	项目数量
自攻螺钉(直径5 × 18 mm)		4
绝缘套(电源端子)		1
六角扳手		1

根据使用场合的不同,可能有多种不同的连接及设定方式请务必仔细阅读使用说明书,选择适当的连接和设定。

- 4. 连接扬声器缆线。
- 5. 连接电源线, 电源控制缆线及地线, 不可违反此顺序。
- 6. 向本机安装装配部件。
- 7. 安装本机。
- 8. 连接蓄电池的负极(-)。

▲注意

- 不得在下列位置安装;
- (不稳定的位置,妨碍驾驶车辆的位置,潮湿的位置,灰尘较多的位 置,受热的位置,知识与农牛相的位置,制强的位置,从主权多置,受热的位置,阳光直射的位置,热气接触的位置) ·不可将本装置安装在绒毯底下,否则,蓄热会导致本装置损坏。 ·将本装置安装在热量容易发散的地点。

- -旦安装完毕,不可在其上放置其它物品。
- · 机器使用过程中, 机体表面会发热升温。 所以其安装地点应该是人
- 和风管的位置。堵塞通风孔的后果是内部温度升高,引起系统故障。
- 在车座, 行李箱底部或车子其它部位打洞时, 应确认其背面没有会受 到损坏的物件,诸如油箱、刹车用配管或线路管套等,千万不可擦伤 或损坏这些物品。
- ·不可安装在驾驶室仪表板,尾部底板或保险气囊等部件之上。 ·将本机安装在车内时,应确保固定牢靠,且不会对驾车造成妨碍。 如 果因为冲击造成本机脱落且撞及人体或保险部件, 就会导致伤害或事
- · 在本裝置安裝之后, 应该确认电气设备, 比如刹车灯、转向信号灯以及雨刷等操作正常。

▲警告


为了防止短路所引起的火灾,在蓄电池的正 极附近连接保险丝或断电器。




▲注意


- ·如果声音输出不正常,应立即关断电源并检查连接是否正确。
- · 在变更开关的设定时,必须首先切断电源。
- · 当保险丝熔断后,要检查缆线是否有短路,并更换上相同规格的保险丝。
- · 检查是否有尚未连接的缆线或与车体相接触的端头。 未连接缆线及其端部的保护帽不可拆掉,以防短路。
- · 扬声器的缆线要分别连接到各自的端子。 共用扬声器的负极缆线或将扬声器端子接 地到汽车的金属部分,都会导致本机停止 工作。
- ·安装之后,请检查汽车的刹车灯、方向指示灯、雨刷等是否正常动作。

* 市售品





■ 4 声道系统







■ 大功率 2 声道系统







■ 2 声道 + 副低音扬声器系统(1)






■ 2 声道 + 副低音扬声器系统(2)





控制盘设在前侧盖板的下面。 需要调整时,请取下盖板。 (参照第15页)



本机为机体内装载了2台立体声的4 声道放大器。 其2台放大器之中一台称为A,另一台则称为 B。 如下所记,可以对应开关切换操作及各种功 能组合系统。

- ① 保险丝 (25A × 2)
- ② 蓄电池端子
- ③ 接地端子
- ④ P.CON(电源控制)端子 控制本机的接通/关闭。

注

控制本机电源。 应务必与全部系统连接。

- ⑤ 扬声器输出端子(A.ch/B.ch)
 - · 立体声连接端子:

当您希望本机作为立体声放大器时,必须使 用立体声连接端子。

所连接的扬声器的阻抗必须为 2 欧姆或更 当多个扬声器被连接时,必须保证每声 道的综合阻抗大于或等于 2 欧姆。

・桥路连接端子:

当您希望本机作为大功率单声道放大器使 用时,可以进行桥路连接。(连接LEFT声 道 RIGHT声道 及SPEAKER OUTPUT 端子)

所连接的扬声器的阻抗必须为 4 欧姆或更 当多个扬声器被连接时,必须保证每声 道的综合阻抗大于或等于 4 欧姆。

▲注意

扬声器的额定输入功率要大于放大器的最大输 出功率。 否则,将造成损坏。

⑥ LINE IN (线输入) 端子 (A.ch/B.ch)

⑦ LINE OUT (线输出)端子

此端子为合成输出分别从放大器 A 和 B输入 的信号

它们总是输出立体声信号而不管 OPERATION (操作) 开关的设定如何。

⑧ 电源指示灯

当电源打开时,电源指示灯点亮。 如果当电源被打开,但该指示灯却不点亮时, 也有可能是因为保护功能被激活。 请检查是 否有出现故障的迹象。 (参照第14页)

- ⑨ FILTER(滤波器)开关(A.ch) 本开关将高通滤波用于扬声器输出。
 - ·HPF(高通滤波器)位置 滤波器将输出高于 "HPF FREQUENCY"控制设 定值的波段。
 - ·OFF(关闭)位置: 滤波器将不进行任何滤波处理, 输出整个 波段。
- ⑩ OPERATION(操作)开关(A.ch/B.ch) 根据本开关的设定,可以选择输入到放大器 A和 B中的信号的放大方法。
 - ·STEREO(立体声)位置 放大器可以作为立体声放大器使用。
 - · MONO (Lch) (单声道-左声道) 位置 只放大从左声道输入的信号。 切换到此位置 可以进行桥路连接,作为大功率单声道放大 器使用。(输入的右声道信号不输出)
- ⑪ INPUT SELECTOR (输入选择) 开关 本开关可以选择被放大器 A 和 B 处理的信号 的输入方法。
 - ・A、B 位置

放大输入到放大器 A 和 B 的两种信号。

· A 位置

使用A、B放大器处理输入到放大器 A 的信 号。

⑫ FILTER (滤波器) 开关 (B.ch)

本开关可以对扬声器的输出进行高通滤波器的 或低通滤波器的滤波处理

- · HPF (高通滤波器) 位置 滤波器将输出高于 "HPF FREQUENCY"控制设 定值的波段
- ·OFF(关闭)位置: 滤波器将不进行任何滤波处理, 输出整个 波段。
- ·LPF(低通滤波器)位置 滤波器将输出低于 LPF FREQUENCY控制设 定值的波段

扬声器的输出将自动切换单声道(L+R)。

⒀ HPF FREQUENCY(高通滤波频率)控制 (A.ch/B.ch)

当把 "FILTER" 开关切换为 "HPF" 时, 可以调整 遮断频率。

⑭ BASS BOOST FREQUENCY(低音提升频 **率)控制(B.ch)** 设定进行提升的低频范围的中央频率。

⑮ BASS BOOST LEVEL(低音提升)控制 (B.ch)

设定进行提升的低频范围电平。

⑯ LPF FREQUENCY (低通滤波频率) 控制 (B.ch)

当把 "FILTER" 开关切换为 "LPF" 时,可以调整 遮断频率.

⑪ INPUT SENSITIVITY (输入灵敏度) 控制 (A.ch/B.ch)

根据与本放大器连接的中心装置的前置输入水 评调节本控制钮。

对于放大器 A 和 B 可以分别设定其灵敏度而 不管输入选择开关的位置如何。

注

关于中心装置的前置输出电平,请参考其使 用说明书。

故障检修

有时被认为是故障的现象,其实是因微小的操作或配线失误而造成。 在要求维修之前,请参照下表稍事检查为盼。

现象	原因	排除方法
	・输入(或输出)缆线未连接。	・连接输入(或输出)缆线。
(保险丝跳断)	· 保护线路可能被触发。	・参考 <保护功能> 一节, 检查连接状况。
	・音量过大。	・请更换保险丝, 减小音量。
	・扬声器电线短路。	·确认扬声器线,解除短路原因后,更换保险丝。
输出电平过低(或过高)	· 输入灵敏度调节不当,没有位于妥当位置。	・调节该控制器。请参考 <控制>。
声音质量很差	·扬声器缆线的极性⊕/⊝连接错误。	・请将缆线的极性⊕/○连接正确。
(声音失真)	· 扬声器缆线的一根被车体螺钉压迫。	・重新连接缆线,使之不再受螺钉压迫。
	・开关的设定可能不妥。	・请参考 <控制>,将开关正确设置。

规格

规格可能会变更,恕不另行通知。

音频部
最大输出功率
額定输出功率(+B = 12.0 V) 普通 (4 欧姆) (20 Hz ─ 20 kHz, 0.05 % THD)
额定输出功率(+B = 14.4 V) 普通(4 欧姆)(20 Hz ─ 20 kHz, 0.05 % THD)
频率响应(+0, -3 dB)
信噪比
共同 使用电压 14.4 V (允许 11 — 16 V) 消耗电流

